

# HAPPIJAC<sup>®</sup>

## Plug & Play Bed-Lift Wiring Diagram

**Relay Control Module location ...** RVIA wiring requirements restrict the length of exposed motor leads to a maximum of ten (10) inches. Therefore, the Relay Control Module must be placed above the motor or on the wall of the coach in close enough proximity to the motor that the 10" motor lead will reach.

