

CA-UR Installation Instructions

NOTE: Rear anchors are installed in the end of the bumper. There is no precise mounting location since a variety of bumpers may be installed. The general guidelines are as follows:

1. Mounting location should be as flat & vertical as possible.
2. Be sure no moldings or bumper caps interfere with the removable coupler.
3. Check back side of selected mounting location to ensure adequate access for tightening nut.
4. Chose a location as far back as possible from the front edge of bumper while giving consideration to the other criteria listed above and center punch and drill a 1/8" pilot hole then enlarge to 1/2". Install Anchor Bolt with 2" fender washer, lock washer & nut.



Flat edges of Anchor Bolt must be Horizontal.

Happijac Company, 505 N. Kays Dr., Kaysville, UT 84037 * (800) 231-7440 * happijac@happijac.com