



**CAUTION:** When beds are not being manually raised or lowered, the **BRAKE MUST BE SET** or beds will drift down and will damage objects or vehicles placed below the beds.

**To Manually Raise the beds:**

1. Unplug the motor
2. Release the brake
3. Turn hex shaft using a 1/2" ratchet wrench.
4. Re-apply brake at desired bed height.
5. Reconnect motor plug.

**To Manually Lower the beds:**

1. Unplug the motor
2. Release the brake
3. Apply downward pressure to the bed platform.  
Bed will slowly drift downward.
4. Re-apply brake at desired bed height.
5. Reconnect motor plug.